



# Flexit S4X/S7X

94245-13  
2018-06

## Reservedelsliste / Sparepart List

Beskrivelse	Description	S4	S7
<b>Motor</b>			
Festebrakett for kontakt	Mounting Bracket for connector	55112	55112
Kontakt 5-pol han	Contact 5-pin male	55111	55111
Kontakt 5-pol hun	Contact 5-pin female	55110	55110
Motor S4 kompl. (etter feb. 2002)	Motor S4 compl. (after feb. 2002)	98333	
Motor S4 kompl. (før feb. 2002)	Motor S4 compl. (before feb. 2002)	98038	
Motor S7 kompl. Venstre	Motor S7 compl. Left		98340
Motor S7 kompl. Høyre	Motor S7 compl. Right		98346
<b>Styring SP 30-40</b>			
<b>Controller SP 30-40</b>			
Koblingsbrett	Connection Terminal	85040	85070
Kondensator drift 2 stk pr. aggregat	Capacitor operation, 2 pcs per unit	101318	55101
Kretskort SP30, V3	Controller Board SP30, V3	80022	80022
Hovedkort V6	Main Controller Board V6	80023	80023
Temperaturføler NTC	Temperaturføler NTC	111156	111156
Rele Schrack RT31L024	Relay Schrack RT31L024	80025	80025
Rep.sett ettervarme, kompl.(etter 10/10-02)	Repair Set el. heating, compl. (after 10/10 -02)	80035	80035
Trafo	Transformer	113876	113877
Koblingsbrett W	Connection Panel W	85050	85050
Kretskort, SP40	Controller Board SP40	80026	80026
Kretskort W (etter sept. 2000)	Controller Board W (after sept. 2000)	80031	80031
Kretskort W (før sept. 2000)	Controller Board W before sept. 2000)	80028	80028
Skjøtekontakt styrepanel 8-pol Res	Splice connector 8-pin Spare	115835	115835
<b>Styring CS 50</b>			
<b>Controller CS 50</b>			
Sentralenhet CU50	Controller Unit CU50	98410	98410
Styringsbryter CI 50	Controller Interface CI 50	09380	09380
Kondensator drift, 2 stk pr aggregat	Capacitor operation, 2 pcs per unit	101318	55101
Trafo	Transformer	113876	113877
<b>Kryssveksler</b>			
<b>Heat Exchanger, Cross</b>			
Kabel m/chassiskontakt RJ45, Res	Cable with splice connector RJ45, Spare	116364	116364
Sjassikont. + ledning (Jack-plugg)	Chassis Contact + cable (Jack plug)	56065	56065
Termofuktføler ISDN	Thermoguard ISDN	56304	56304
<b>El Varme</b>			
<b>Heating Battery, Electrical</b>			
Overhetningstermostat	Overheat Thermostat	55082	55082
Branntermostat	Overheat Thermostat, manual reset	55083	55083
EV S4 1675W (FV S4 TT)	Afterheat S4 1675W (Preheat S4 TT)	56328	
EV S4 1650W (før jan. 2001)	Afterheat S4 1650W (before jan. 2001)	56066	
FV S4 975W (EV S4 TT)	Preheat S4 975W (Afterheat S4 TT)	56330	
FV S4 975W (før jan. 2001)	Preheat S4 975W (before jan. 2001)	56033	
FV S7 975W EV S7 TT)	Preheat S7 975W (Afterheat S7 TT)		56033
EV S7 2000W	Afterheat S7 2000W		56142
FV S7 TT 2000W	Preheat S7 TT 2000W		56142
<b>Vannvarme (W)</b>			
<b>Heating Battery, Water (W)</b>			
3-veis ventil	3-way Valve	56232	
Lukkesjeld inkl. motor Ø 200	Damper incl. motor Ø200	14481	
Motor til 3-veisventil (24 V)	Motor, 3-way Valve	56234	
Frostføler	Frostguard	56222	
Vann batteri S4	Water Battery S4	56278	
<b>Chassis</b>			
<b>Chassis</b>			
Dør komplett (høyre)	Door complete (Right)	98702	98705
Dør komplett (venstre)	Door complete (Left)	98703	98706
Tettningslist	Sealing Band	55234	55234
<b>Filter</b>			
<b>Filter</b>			
Filterholder	Filter Frame	57171	
Filtersett komplett	Filter Set complete	12318	12313